

813 A/B

Installation guide



Parts list (Subject to actual size; each type of screws and washers has **space**)

General accessories						
	Five wheels	One gas rod	One chassis	One seat cushion	One backrest	Two armrests
Optional accessories						
	Galvanized steel feet and foot covers		Aluminum alloy feet		Plastic feet	
					Note: Before installing the chair, please sort the screws and measure the length of the screws for installation	
A headrest	A decorative cover	Two headrest screws (M6*20)				



Installation icon (Subject to actual size)

1 Press the wheel into the chair leg	2 Put the air rod into the middle hole of the chair leg	3 Put on the foot cover	4 Use three M6*35 armrest screws and on the left and right sides to connect the armrest and the seat cushion
5 Use four M6*35 mechanism screws to add spacers to connect the seat cushion and the chassis	6 Use three M8*35 backrest screws + elastic media + spacers to connect the backrest and the chassis, pay attention to distinguish the front and back	7 Align the upper half of the assembled chair and put it into the air rod	8 1. Two M6*20 headrest screws to install the headrest on the backrest 2. Then put on the decorative cover and the installation is complete
0 1 2 3 4 5 6 7 8 9 10 cm			

Note: Before installing the chair, please sort the screws and measure the length of the screws for installation