

Important Notes

1. Please use this chair indoors.
2. Avoid placing this chair in a location where it will be subjected to high temperature, humidity, or be exposed to direct sunlight, since these can cause discoloration or mold.
3. Please avoid water and sweat on the PU arm-pad.
4. The PU casters will be damaged if often sliding on the humid and dirty floor.
5. Please keep the mesh material away from sharp metal, such as knife and key, and away from fire also.
6. The lubricating oil which is inside the mechanism will be running out after using for a long time. So, if you hear some noises from the chair, please contact us for maintenance.
7. The chair only can be dry-cleaned. Otherwise, the metal parts may appear oxidation rust and cause some difficult operation.
8. Inspecting the chair completely and make sure that all screws are tighten.
9. The pictures in this manual are for reference only.









RAY-M01





User Manual



RAY-M02

Product List

RAY-M01	1 Chair Body×1 	2 Headrest×1 	3 Castor×5 
	4 Gaslift×1 	5 Plastic cover ×1 	
	6 Base×1 		



RAY-M02	1 Chair Body×1 	2 Base×1 
	3 Gaslift×1 	4 Castor×5 

1

Adjustment Guide

Backrest Tilt Tension Adjustment

Turn the tension adjustment knob under the right side of the seat in the "+" direction to increase the reclining tension. Turn the knob in the "-" direction to decrease it. Adjust the tension according to your physical size and preference.




14

Adjustment Guide




Backrest Reclining Angle Adjustment

Rotating backwards the handle under the right side of the seat to adjust the backrest reclining angle. While leaning back against the backrest to the desired angle, rotating forwards the handle to the middle position to secure. There are 4 locking positions within 22 degrees of reclining.




13

Assembly Instructions




Castor Assembly

Press the castors firmly into the holes on the base.



Gaslift Assembly


Insert the gaslift into the hole of the base.




Assembly Guide

2

Assembly Instructions




3



Headrest Assembly

Insert the headrest into the backrest.



Base Assembly

Place the seat cushion on the gas lift.

Adjustment Guide




Seat Depth Adjustment

Rotating forwards the handle under the right side of the seat to adjust the seat depth. While to the desired depth, rotating backwards the handle to the middle position to secure. There are 5 locking positions, 12 mm for each, adjustable range is 60mm in total.



12

Adjustment Guide



Seat Height Adjustment


Pull down the handle on the right side of the seat to adjust the seat height. Release the handle to lock at your desired height.

Setting your seat at an incorrect height can lead to back fatigue. At the right seat height, your feet are flat on the floor and your knees are at a 90 degree angle.




11

Headrest Disassembly Guide ①




Headrest Disassembly

Hold the headrest support to raise, when it reaches the position as shown in the picture, press the stuck position of the headrest support, then raise again at the same time.



4

Headrest Disassembly Guide ②



Plastic Cover Assembly

After disassemble the headrest, inserting the plastic cover into the hole of the backrest.

5

Adjustment Guide




Armpad Width Adjustment

Hold the armpad, moving left or right to adjust the width. Adjustable range is 25mm.


Armpad Forward & Backward Adjustment

Hold the front edge of armpad to adjust forward and backward. Adjustable range is 55mm.



10

Adjustment Guide



Armrest Height Adjustment

Lift the arm pads to adjust the height. Lift them to the highest level to return the armrests to the lowest position. There are 17 locking positions, 5mm for each, adjustable range is 85mm in total.


Armpad Angle Adjustment

You can adjust the horizontal angle of the arm pads outward (18 degrees) or inward (20 degrees) directions to suit your purposes.




9

Adjustment Guide



Headrest Height Adjustment

Hold the headrest to raise or lower the height, adjustable range is 65mm.



Headrest Angle Adjustment

Holding the headrest to adjust the angle, adjustable range is 38 degrees.

6


Adjustment Guide

Backrest Height Adjustment

Grasp the bottom of backrest to raise or lower the height. Lift the backrest to the highest level then return to the lowest position automatically. There are 14 locking positions. Adjustable range is 70mm, 5mm for each.





7



Adjustment Guide

Activity Lumbar Support

The lumbar support will automatically be adjusted according to your body weight and shape as you lean on it. You will receive the appropriate support without adjustment.



Lumbar Forward and Backward Adjustment

Grasp the lumbar and pull out to adjust the depth, adjustable range is 25mm. It only can be pushed back to the original position when pulling out to the maximum.

8